perma CLASSIC - Quick Start Guide

1. Predefine installation / Select lubricant, discharge period + connecting parts



2. Prepare lube-poir









For remote mounting: Prefill lube-point and any grease lines / connections luse the same grease that is contained in the lubrication system



(refer to perma CLASSIC installation guide for details)



